

## Homemade air-dry clay recipe:

- 1) Take a toilet paper roll (preferable a cheaper brand for does not hold up well) and weigh 24 grams worth of torn off paper.
- 2) Place dry bits of toilet paper in a bowl and cover with very warm water, let soak until easy to shred with hands.
- 3) Ring out excess water just until the wet paper weighs 200 grams.
- 4) Place in a large bowl and add:
  - 1/2 cup flour
  - 1/2 cup corn starch
  - 1/2 cup of wet premixed polyfilla (I used Bostix brand hole and crack filler from the warehouse, only \$10.)
  - 3 tablespoons of mineral or baby oil
  - food coloring to tint (if you want)
- 5) Using a blender with doe/bread mixer attachment blend until well mixed and pretty smooth.
- 6) Gradually add and mix in another 3/4 cup of flour
- 7) Take out of bowl and knead into cornstarch covered surface until smooth, if too sticky add more cornstarch and knead until pliable and not too sticky.

Use as desired making sure not to use too thick for like regular clay will be hard to dry. You could build up under structures with wire and masking tape and then smooth on clay. Also smearing a tad of white craft glue on sub straights helps glue to stick. You can back on baking paper in the oven to speed dry times, but please be careful not to cook for more than 10 minutes or to burn for bostix is toxic when burning. I do not think any worse than sculpty really.